


Replay ST (default setup)



How Replay ST Works:

Replay Client ext 100 and Replay Client ext 101 generate voice files and send them to the Replay Server PC. Replay Nova Manger processes files to make them available to TAPIT NOVA Reports. TAPIT NOVA User clicks on a call record on a detail report to listen to corresponding voice files.